



**This antenna mounting bracket is designed for installation on these specific vehicles:**

**Ford F-150: 2015-2018**  
**Ford Superduty F-250,**  
**F-350/450/550 2017-2018**  
**Expedition 2018**

## ***FO3ANTNCG-R*** ***Right side install***

### Tools Required:

10mm socket and driver, or 10mm box end wrench

### Install location:

Left front fender



**Step 1) Set the parking brake. Open hood and locate 10mm bolt near the center of the right side (passenger side) front fender. Remove bolt.**

**Step 2) Align the antenna bracket with the bolt hole, reinstall the bolt and tighten.**

**NOTE: To avoid galvanic corrosion between the aluminum body and stainless steel bracket, isolation tape has been attached to the bottom bracket surface, do not remove. If needed for grounding, the stainless steel star washer should be placed ONLY between the bolt head and bracket and should not penetrate the painted surface.**

**Step 3) Insert the NMO or required connector to mate with the antenna and tighten securely.**

**NOTE: NMO type mounts are designed to be installed from the top of the bracket, coax first. Due to the 14 gauge thickness of the bracket, some NMO mounts have a hard time shifting into the 3/4" hole. The Larsen NMO-K mount does not have that problem.**



NCG Company may not be held liable for any damage to the vehicle before, during or after the installation or removal of this antenna bracket.  
NCG may not be held liable for any personal injury resulting from accident or improper installation.



National Communications Group Co., Ltd  
Chino, CA 800-962-2611  
909-393-6133 Fax: 909-393-6136