This antenna mounting bracket is designed for installation on these specific vehicles:

FORD SuperDuty 2011-2014
F-250, F-350, F-450, F-550

Model#: SD2ANTPF

Tools Required:

10mm socket and driver, or 10mm box end wrench

Install location:

Left front fender

Please Read: Always check for continuity between the bracket and chassis ground. If there is a problem with grounding, place the provided star washer between the bracket and the fender.

Step 1) Set the parking brake. Open hood and locate 10mm bolt near the back of the front fender. Remove bolt.

Step 2) Align the antenna bracket with the bolt hole. Reinstall the bolt and tighten.

Step 3) Insert the NMO or required connector to mate with the antenna and tighten securely.

NCG Company may not be held liable for any damage to the vehicle before, during or after the installation or removal of this antenna bracket.
NCG may not be held liable for any personal injury resulting from accident or improper installation.

National Communications Group Co., Ltd
Chino, CA 800-962-2611
Fax: 909-393-6133
www.natcommgroup.com